

Extruder Bearing Hinge - WA-110-S

Steps 1 and 2

This part is show flipped so the counterboring is created on the correct side.


Drill nine (7) 1/4" holes in the various locations.

Counterbore a 1-1/2" half the thickness of the material.

Drill four (3) counterbores to 1/8" in depth to provide for 3mm screws.

Step 2: Drill the mounting holes using the center of the counterbores.

Cut the lines show on the corner.



Part Shown on Reverse Side